



INSTALLATION INSTRUCTIONS FOR ALL FLAMECRETE DIY SQUARE AND RECTANGLE FIRE TABLE KITS

- 1. When your material arrives make sure to inspect it for any damage while the shipper is there. Please take pictures of any damage. Once you are satisfied with your shipment, break it down in the area where it will be installed. We recommend that you watch the installation video on line before you start. BECAUSE THIS IS A PRECUT KIT YOU SHOULD NOT HAVE TO CUT ANY PANELS OR TOP PIECES. IF YOU THINK SOMETHING IS WRONG CALL AND MAKE SURE BEFORE YOU CUT.**
- 2. We recommend you mark out the exact place where your fire table will be installed.**
- 3. Once this is done, you are ready to start putting your fire table together.**
- 4. Your fire table will be ready to install but you need to take a stiff broom or brush and make sure that all surfaces that the adhesive will make contact with are dust free. If you want your fire table to be permanently attached to the surface that you are installing it on, then use your adhesive on that surface, then install the panels.**
- 5. On the square and rectangle fire tables you will install the adhesive only on the end pieces that fit between the front and rear panels. You will use 2 continuous beads per end, for a total of 8 beads of adhesive.**
- 6. Then put the end pieces and front and rear panels together. Push them tight. Then using the screws in your kit, put 3 screws at all 4 joints. For a total of 12 screws. Do not over tighten the screws, and be sure to flush up all edges.**





- 7. The only time numbers 7 and 8 will change is when the front and rear panels are over 48” long. This circumstance will create a seam in the front and rear panels only. The same adhesive application will apply.**
- 8. You are now ready to install the top piece. Before you install the top piece make sure that you have all of your natural gas or propane gas fitting, valves and whatever else you may need installed. You may now go ahead with the installation of the top piece. Since your fire table top will have a 12” over hang on all 4 sides, it is necessary to make sure you know where to place it on the table top before you apply the adhesive.**
- 9. Apply 2 continuous beads of adhesive on the top of each panel. Then put the top on and even up all 4 sides. Then take the remaining screws and using an equal number in each panel, attach the top to the base. Don’t over tighten the screws.**

If you are purchasing all of the gas or propane fixtures to complete your fire table from us, you will receive additional instructions. If you purchase these items from someone else make sure that you follow their instructions. YOU NEED TO CHECK WITH YOUR LOCAL BUILDING DEPARTMENT REGARDING CODES FOR THE INSTALLATION OF ANY GAS PRODUCTS. WE HIGHLY RECOMMEND THAT YOU CONTACT AND USE A LICENSED OR CERTIFIED PROFESSIONAL IN THE INSTALLATION OF ALL GAS PRODUCTS.

Thank you for purchasing your new fire table from FlameCrete.com. If you have any questions regarding the above process we suggest that you review the video regarding the installation process or call us.

